



WHERE DO I MEASURE TO?





Rooflight Measurement

Our stock rooflights take the critical dimension measurement of the external weathered kerb. Please refer to the specific product drawings for details on kerb dimensions.

Glazing Vision Pitchglaze Measurement

Pitchglaze roof windows take the critical dimension measurement of the Internal Viewable Width

It is important that you allow 61mm on all four sides between the internal viewable width and the supporting structure to allow for internal finishes.